

Getting Started

Included in the Package:

1. SocialDistancer™ Wearable PPE
2. USB Charging Cord
3. Lanyard

Before using:

1. Connect PPE to USB charging cord
2. Plug opposite end of USB cord into an appropriate USB port (e.g. laptop, charging station).
3. Allow PPE to fully charge – red light means charging
4. Full charge is indicated when the red light turns off and a blue light is illuminated.

SocialDistancer is a trademark of ARIN Technologies

Version: 060920

Daily Use

The blue light indicates that the PPE is active and ready to be used.

There is no “on/off” button.

PPE should be fully charged daily.



Alerts & Data

When one PPE comes in proximity of another PPE, audible alerts will notify the users.

Alert Distances:

- 2 meters (6.6 feet) – 2 Hz signal
- 1 meter (3.3 feet) – 4 Hz signal

Data Collection, Storage & Retrieval:

Data is collected and stored on each PPE when PPE's are within 2 meters of each other.

Data includes ID, duration, and nearest distance for each interaction.

No personal data is stored.

Up to 300 interactions are stored.

Data is automatically uploaded to hub and cloud storage service.